

This warranty does not cover normal wear and tear, abusive use or misuse, modification, tampering or by any other cause not related to either materials or workmanship. This warranty does not apply to products used for any industrial, professional or commercial purposes.

**NOTE:** dreamGEAR will not process any defective claims without a Return Authorization Number.

877-999-DREAM (3732) (U.S. and Canada only)

Consumer Support Email: [support@dreamgear.net](mailto:support@dreamgear.net)

www.isound.net

# Control

[illegible]

**Pause/Sieste**

Après une sieste de 05, 10, 20, 30 ou 45 minutes, vous pouvez choisir de changer la sieste en mode veille.

Unité est éteinte sans la fonction

Après avoir appuyé sur 05, 10, 20, 30 ou 45, vous pouvez choisir de changer la sieste en mode veille.

Unité est éteinte sans la fonction

**Rétroéclairage**

Après l'appui sur l'alarme, l'alarme est déclenchée; l'alarme s'arrête dans 30 minutes, et ce que vous désirez l'alarme.

**Sound**